

Score Board Operating Instructions (Lebrun)

To Power On:

- Turn the power button to “ON” position
- The power button is location the right side of the clock

To Start a New Game:

- Select “NEW GAME”

Note: Once game information is entered; hit the “START / STOP” button to start/stop the game. The game will not start until you hit this button.



To Set the Game Time:

1. Press one of the times that are preset (10:00, 12:00, 15:00, 20:00); or
2. Enter time by pressing “CUSTOM TIME”

To Add Warm-Up Time:

1. Press “OPTION”
2. Press “WARMUP”
3. Press “SET MINS” and enter the warmup duration. (Usually three minutes)

To Add Penalty Minutes:

1. Press “HOME PEN” or “AWAY PEN”
2. Press ADD
3. Enter time of penalty (either custom or pre-set 2 MIN, 4 MIN, 5 MIN, 7 MIN)

Note: You can also delete penalties from this same screen by pressing “EDIT”

To Add or Delete Score:

1. Press “HOME SCORE” or “AWAY SCORE”
2. Press +1 or -1

To Change a Period Manually:

1. Press “Period”
2. Enter in the period number you wish to display on the scoreboard

To Go Back to Previous Screen:

1. To go back to previous screen, press the “BACK” button



To Delete a Number Entered:

2. Press the “DELETE” button

